



AFFORDABLE ADJUSTABLE DESKS FOR EVERYONE

Little Soleil DX

Children's Adjustable Desk

Assembly Guide



REV-1609A

Table of Contents

CAUTION, USE& LIABILITY.....	3
PARTS & COMPONENTS LIST.....	4
ASSEMBLY INSTRUCTIONS.....	5
CARE INSTRUCTIONS.....	10
TECHNICAL SPECIFICATIONS.....	10
WARRANTY INFORMATION.....	11
CONTACT INFORMATION.....	11

CAUTION, USE& LIABILITY

CAUTION



Keeps small items away from small children. Keep hands off pinch points.




Do not sit or stand on the desk. Do not crawl or lie under the desk.

USE & LIABILITY

This children's adjustable desk is designed for use in an indoor environment and dry work area only .The desk height is adjustable so that it can be positioned at the most suitable height for your growing child. Any other use is at user's risk .Under no circumstance does the manufacture accept warranty claims or liability claims for damages caused from improper use or handling of the desk.

PARTS & COMPONENTS LIST



No.	COMPONENT LIST	QTY
1	Leg	2
2	Crossbar	1
3	Crank	1
4	Top	1
5	Spindle	1
6	Drawer	1
7	Drawer panel	1
8	Shelf	1
9	Shelf holder	2
10	Phillips screwdriver	1
11	Screw A	1
12	Allen wrench	1
13	Screw B	22

ASSEMBLY INSTRUCTIONS

BEFORE YOU BEGIN

- Lay out all components and hardware to ensure that you have all the parts listed on the parts page. Contact manufacturer on Page 11 for missing parts and components.
- Assemble on soft and non-abrasive surface to avoid scratch or damage to the top.
- There are two types of screws needed for assembly – A and B. Only Step 4 requires Screw A. Use Screw B for all other steps.

STEP 1

Secure legs to the desk top. Please take note of the leg and foot, and make sure the side that has crank direction printing face outside and longer end of the foot correspond to that of the desk top.



STEP 2

Crank can be installed on either side. Take note of the spindle's both ends. One end has hexagon rod and the other end has tube with a small opening. Insert hexagon end to the side that crank will **NOT** be installed.




STEP 3

Thread crank thru the leg and into the "tube" end of spindle. There is one mounting holes on the crank. Make sure that you can see the hole thru the opening of tube.



STEP 4

Use Screw A to secure crank to the spindle. Half-tighten the crank and make sure it turns freely before tightening the screws fully. Slide the crank to the left or right to make adjustment if needed.

**STEP 5**

Secure crossbar with Screw B, two on each side.



STEP 6

Follow pre-drilled holes and assemble the drawer.

**STEP 7**

Follow pre-drilled holes and secure drawer to the back of the top.



STEP 8

Follow pre-drilled holes to secure shelf to the holders

**STEP 9**

Clamp the shelf onto the rear edge of the desk.



STEP 10

Adjust leveling studs if needed.

**CARE INSTRUCTIONS**

Recommend checking the screws and bolts several times a year to ensure they stay tight. Desk is intended for use in dry, indoor areas. Avoid extended exposure to direct sunlight. For all surfaces: wipe clean with a damp cloth and a weak cleaning solution, and then dry with a clean and dry cloth.

TECHNICAL SPECIFICATIONS

Product Dimensions	43W X 28D X 21 – 30”H
Height Adjustment Range	21-30”
Split Top Size	28W X 18”D
Split Top Tilt Angle	0-75°
Weight	64 Lbs

WARRANTY INFORMATION

SCOPE OF WARRANTY

Apex Furniture LLC ("ApexDesk") warrants to the original purchaser its new desk (except for components not warranted under "Exclusions") manufactured by Apexdesk to be free from defects from material and workmanship under normal use and service. ApexDesk's obligation under this warranty is limited to the repair or replacement, at ApexDesk's sole option, of the parts or products the defect of which are reported to ApexDesk within the applicable warranty period and which upon examination by ApexDesk prove to be defective .

APPLICABLE WARRANTY PERIOD

The applicable warranty period, measured from the date of delivery to the original user, shall be three (3) years limited warranty for lifting and tilting mechanism on all warranted children's desk.

EXCLUSIONS

This limited warranty doesn't cover and ApexDesk shall not be liable for the following :(1) repairs and replacements because of misuse ,abuse ,negligence, alteration ,accident ,freight damage ,or tampering ; (2) products which are not installed ,used, stored and properly cleaned as required in the ApexDesk "Assembly Guide" for this products ; (3) products considered to be of consumable nature ;(4) Shipping to or from repair center; (5) accessories or parts not manufactured by ApexDesk ; (6) charges by anyone for adjustments ,repairs, replacement parts , installation ,or other work performed upon or in connection with such products which is not expressly authorized in writing in advance by ApexDesk .

Exclusive Remedy

ApexDesk's only obligation under this warranty is the repair or replacement of defective parts. ApexDesk shall not be liable for any direct, special, indirect, incidental, exemplary, or consequential damages or delay, including, but not limited to, damages for loss of profits or loss of use.

CONTACT INFORMATION

Apex Furniture LLC ("ApexDesk")

18467 Railroad Street

City of Industry, CA 91748

Email support@apexdesk.com

(877) 516-DESK

www.apexdesk.com

For technical assistance, please call us or visit at www.apexdesk.com/support